

# 9x4 Setup Instructions

Example ONLY

From each satellite LNBFs you need to run 2 feeds  
(13v + 18v)

Leave all the "dials to default and all the white dip-switches to default

In this example you will be taking 4 SATs  
(82 + 91 + 110 + 119) to 4 FTA receivers

**SAT 1** = A+B (82 W)

**SAT 2** = C+D (91 W)

**SAT 3** = E+F (110 W)

**SAT 4** = G+H (119 W)

SAT	22KHZ	DISEQC
SAT 1 = A+B	Off	1
SAT 2 = C+D	On	1
SAT 3 = E+F	Off	2
SAT 4 = G+H	On	2

For each sat you will following in your FTA box  
(82 + 91 + 110 + 119)

OPTION	SAT	SAT	SAT	SAT
	A+B	C+D	E+F	G+H
	82	91	110	119
<b>DISEQC</b>	1	1	2	2
<b>22KHZ</b>	Off	On	Off	On

All 4 receivers to have 4 satellites must be FTA as we have NOT tested this for NON-FTA boxes. Also you can NOT use DISHPRO LNBFs.

-- END